




1. PRINT AND CHECK SCALE USING 1" REFERENCE SQUARE AND PROFILE DIMENSIONS. SCALING IS CRITICAL, IT MAY BE NECESSARY TO ENLARGE OR REDUCE PRINT TO OBTAIN PROPER SCALE.
2. STICK TEMPLATE TO THICK CARD SUCH AS A FILE FOLDER AND CUT AROUND OUTER EDGE OF PROFILE.
3. LOCATE TEMPLATE IN WHEEL CENTER AND ROTATE TO ENSURE 3mm CLEARANCE AT ALL POINTS. PAY SPECIAL ATTENTION TO WHEEL WEIGHTS.

1" / 25.4mm
SQUARE

STILLEN Brake Division

BRAKE KIT PROFILE

APPLICATION

BMW F30/F22 REAR RADICAL PROFILE

PART NUMBER

APR6480