



1. PRINT AND CHECK SCALE USING 1" REFERENCE SQUARE AND PROFILE DIMENSIONS. SCALING IS CRITICAL, IT MAY BE NECESSARY TO ENLARGE OR REDUCE PRINT TO OBTAIN PROPER SCALE.
2. STICK TEMPLATE TO THICK CARD SUCH AS A FILE FOLDER AND CUT AROUND OUTER EDGE OF PROFILE.
3. LOCATE TEMPLATE IN WHEEL CENTER AND ROTATE TO ENSURE 3mm CLEARANCE AT ALL POINTS. PAY SPECIAL ATTENTION TO WHEEL WEIGHTS.

1" / 25.4mm
SQUARE

<i>STILLEN Brake Division</i>	
BRAKE KIT PROFILE	
APPLICATION	BMW M4 REAR RADICAL PROFILE, 380mm
PART NUMBER	APR7170